

OnGuard Monitor

Browser-based Integrated Alarm, Video and Device Control for OnGuard Systems



Overview

The OnGuard® Monitor client offers a lightweight, browser-based alternative to the OnGuard Alarm Monitoring Windows® application and enables basic alarm, video and status monitoring without client installation or upgrades. Users can securely access OnGuard system events and alarms through a supported web browser on their desktop, laptop or tablet. OnGuard Monitor client features browser-based viewing of OnGuard system maps, bringing facility layouts and dynamic system feedback to any device and delivering actionable insights.

Based on the latest HTML5 standards, OnGuard Monitor client features a responsive user interface and supports a wide range of hardware platforms and operating systems. This client is one of several browser clients available within the OnGuard platform, allowing installation-free user access to an OnGuard system.

The flexible OnGuard Monitor interface provides a simplified, customizable view of OnGuard system activity. Multiple custom layouts can be created and stored, ensuring critical security information is always easily available. The OnGuard Monitor client offers feature-rich video viewing, including support for digital zoom, audio, and enhanced video playback control. Interactive maps add a powerful, visual component to browser-based OnGuard system monitoring.

Features & Functionality

- The OnGuard Maps feature offers pan and zoom views and flashing alarm notifications
- Context-sensitive OnGuard Maps action menus enable operators to open doors, watch video and quickly trace activity
- View alarm details as well as clear, acknowledge and mark alarms in progress
- · Simultaneously show multiple filtered alarm lists
- View live video, recorded video and OnGuard events side-byside for maximum insight
- Support for Milestone XProtect® video recording platform, as well as the LenelS2™ NVR platform, expands viewing options
- Supports digital zoom and playback speed control including forward and reverse
- · Offers snapshot capture and download
- Video viewing includes optional audio support
- Display an interactive hardware tree noting any offline devices
- Status and control for LenelS2 access devices, including reader mode, open door, input masking and output control
- Modern search-as-you-type (incremental search)
- · Design and save custom screen layouts
- Displays cardholder photo upon entry
- · Flexible alarm list sorting and filtering
- Customize alarm list by adding, removing and rearranging columns
- Support for OnGuard monitor zones and user permissions



OnGuard Monitor client

Prerequisites for OnGuard Monitor client

- · OnGuard system version 7.5 or higher
- To display video, OnGuard system version 7.5 and cameras connected to LenelS2 Network Video Recorder (LenelS2 NVR) or Milestone XProtect video management system are required
- For OnGuard Enterprise systems, OnGuard Monitor client can be purchased and installed on any region or master

Please note: The OnGuard Monitor client is licensed on a per-concurrent-seat basis.

OnGuard Alarm Monitoring Windows client features not included in OnGuard Monitor


- · Full-time security operations center applications
- Status and control of non-LenelS2 hardware, such as intrusion, fire and video devices
- OnGuard Monitor Station functions, such as forwarding and highlighting of alarms
- Sending email notification of alarms
- Control or display of local or global I/O, anti-passback and device groups

Browser Compatibility

Browser	Compatible
Google Chrome™	Yes
Microsoft Edge®	Yes
Microsoft Internet Explorer® 11	Yes
Apple Safari® iOS	Yes
Apple Safari® macOS®	Yes



Customized view with OnGuard Maps feature



Customized view with the OnGuard Monitor client Cardholder Verify feature



Integrated alarm, video and device management



LenelS2.com

(866) 788-5095

Specifications subject to change without notice.

